

FULL HEIGHT JAMB STUD ATTACHED TOGETHER W/ (2) #10–16 SCREWS @ 12" O.C.

ATTACH CLOSURE TRACK TO FULL HEIGHT JAMBS W/ (4) #10–16 SCREWS EA. LEG @ HEADER LOCATION

SECTION OF 600T125–54 W/ (8) #10–16 SCREWS TO FULL HEIGHT JAMB STUDS. (@ HEADER)

600T125–54 WEB STIFFENER W/ (4) #10–16 SCREWS LOCATE WEB STIFFENER AT GIRDER LOCATIONS

STEEL STUD HEADER (2) STUD MEMBERS (2) TRACK MEMBERS

ATTACH HEADER TO TRACK W/ (4) #10–16 SCREWS @ EACH LEG

ATTACH HEADER MEMBERS TOGETHER W/ (2) #10–16 SCREWS @ 12" O.C.

SHOULDER JAMB STUD

CLOSURE TRACK (54 MIL) ATTACH TO JAMB STUDS W/ (2) #10–16 SCREWS @ 12" O.C. (1) EACH LEG

∠ 2"x2"x14 GA. (50 KSI) x 0'–5 1/2" LONG W/ W/ (4) #10–16 SCREWS @ EACH LEG

ATTACHED CLOSURE TRACKS TOGETHER W/ (2) #10–16 SCREWS @ 12" O.C.

TELLING™
BUILDSTRONG
6272 CENTER STREET
MENTOR, OHIO 44060
PHONE: 440–974–3370

DETAIL IS FOR REFERENCE ONLY. NOT FOR CONSTRUCTION.

DETAIL PROVIDED BY:
EXCEL ENGINEERING
100 CAMELOT DRIVE
FOND DU LAC, WI 54935
PHONE: (920) 926–9800

LOAD BEARING

HEADER – JAMB ATTACHMENT