



| W5 | HOT WATER INLET FOR PERISTALTIC 1/2" NPT |
|------|--|
| W4 | COOLDOWN INLET 1" NPT CONNECTION |
| W3 | THIRD WATER INLET CONNECTION 2" NPT, OPTIONAL |
| W2 | COLD WATER INLET CONNECTION 2" NPT |
| W1 | HOT WATER INLET CONNECTION 2" NPT |
| S1 | STEAM CONNECTION 1 1/4" NPT |
| L2 | PERISTALTIC SUPPLY |
| L1 | SOAP CHUTE |
| F3 | GROUT HOLES |
| F2 | 1 1/16" DIAMETER ANCHOR BOLT HOLES, USE $5/8" \times 6"$ |
| | BOLTS MINIMUM. (1) BOLT PER PAD MINIMUM. |
| F1 | FOUNDATION BASE PADS, 4 PLACES |
| E5 | REAR CONTROLS |
| E4 | EMERGENCY STOP |
| E3 | MilTouch-EX™TOUCH SCREEN CONTROLLER |
| E2 | HIGH VOLTAGE CONTROL BOXES |
| E1 | MAIN ELECTRICAL CONNECTION |
| D2 | OPTIONAL DUAL DRAIN TROUGHS |
| D3 | OPTIONAL DUAL DRAINS, 10" DIAMETER |
| D2 | SINGLE DRAIN TROUGH |
| D1 | STANDARD DRAIN, 10" DIAMETER |
| B2 | AUTOSPOT MOTOR |
| B1 | BRAKE AIR CYLINDER |
| A2 | STAPHAIRTROL, VENT 8"[203] |
| A1 | COMPRESSED AIR INLET 1/4" NPT |
| ITEM | LEGEND |
| | |

W6 OPTIONAL VACUUM BREAKER

NOTES

- SHIM TO LEVEL THE MACHINE AND ALLOW FOR 1" [25] MINIMUM GROUT. ANCHOR WITH ONE ANCHOR BOLT PER PAD, MINIMUM. USE 5/8" X 6" BOLTS, MINIMUM. SEE INSTALLATION MAINTENANCE MANUAL FOR FURTHER INSTRUCTIONS.
- "STEAM HAMMER", CAUSED BY WET STEAM OR CONDENSATION, MAY BE PREVENTED BY INSTALLING A TRAP IMMEDIATELY BEFORE THE STEAM VALVE.
- 3 DRAIN VALVE MAY MOVE \pm 1-1/2 [38] IN ANY DIRECTION DURING OPERATION AND MUST NOT BE RIGIDLY CONNECTED TO DRAIN.
- SHADED AREA ARE BASE PLATES WHICH MUST BE CONTINUOUSLY SUPPORTED ON 1"[25] THICK GROUT. ALSO, THIS 1"[25] OF GROUT IS NECESSARY TO INSURE THE STAPH GUARD BRAKE WILL NOT HIT THE FLOOR.

- THE STAPH CUARD BRAKE WILL NOT HIT THE FLOOR.

 6 AS OF THIS WRITING, THE MINIMUM CLEARANCE REQUIRED BY U.S. NATIONAL ELECTRIC COOSES, FROM ELECTRIC BOX TO ANY OBJECT IS:

 36 [914] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL.

 42 [1067] IF OBJECT IS AN UNGROUNDED (INSULATED) WALL.

 43 [129] IF OBJECT IS AN TUVE PART.

 CHECK LOCAL ELECTRIC CODES FOR FURTHER RESTRICTIONS.

 5 CUSTOMER TO SUPPLY CIRCUIT BREAKER OR FUSED BRANCH CIRCUIT DISCONNECT (GAFETY) SWITCHES WITH LAG TYPE FUSES FROM POWER SOURCE TO MACHINE. A SEPARATE GROUND WIRE MUST BE CONNECTED FROM DISCONNECT TO EQUIPMENT.

 4 BASELINE "Z" IS THE SAME FOR ALL MILLOR MACHINES AND IS SHOWN ON ALL DIMENSIONAL DRAWINGS. THE DISTANCE BETWEEN BASELINE "Z" AND THE FINISHED FLOR MAY VARY (WITH CHANGES IN FLOOR HEIGHT) AS REQUIRED TO INSURE THAT BASELINE "Z" IS HORIZONTAL AND ALL COMPONENTS REQUIRING GROUT ARE SET ON A MINIMUM 1"[25] THICK GROUT BED.

 3 USE REFERENCE LINES "X", "Y", AND "Z" TO LOCATE ALL SERVICE CONNECTIONS.

 2 NUMBERS IN BRACKETS [] DENOTE DIMENSIONS IN MILLIMETERS.

 1 ALL DIMENSIONS SHOWN ARE APPROXIMATE, SUBJECT TO NORMAL MANUFACTURING TOLERANCES, AND TO OCCASIONAL CHANGES WITHOUT NOTICE THROUGH REDESIGN AND/OR RELOCATION OF COMPONENTS, ETC. DO NOT USE FOR CONSTRUCTION MACHINE. FACTORY MUST BE CONSULTED FOR DIMENSIONS IF MACHINE IS TO BE MOVED THROUGH NARROW OR LOW CORRIDORS OR OPENINGS.

MOST REQUIATORY AUTHORITIES (INCLUDING OSHA IN THE USA) HOLD THE OWNER/USER ULTIMATELY RESPONSIBLE TO MAINTAIN A SAFE WORKING ENVIRONMENT. ACCORDINGLY, THE OWNER/USER MUST REOCONIZE ALL PORESEABLE SAFETY HAZARDS, FURNISH SAFETY INSTRUCTIONS AND GUIDANCE TO ALL PERSONNEL WHO MAY COME IN CONTACT WITH THE INSTALLATION, AND PROVIDE ALL NECESSARY ADDITIONAL SAFETY GUARDS, RECKES, RESTRANTS, DEVICES, ETC., NOT FURNISHED BY THE EQUIPMENT MANUFACTURER OR VENDOR.

THE FLOOR AND/OR OTHER SUPPORT COMPONENTS MUST HAVE SUFFICIENT STRENGTH AND RIGIDITY WITH DUE CONSIDERATION FOR NATURAL OR RESONANT FREQUENCY THEREOF) TO WITHSTAND THE FULLY LOADED WEIGHT OF THE MACHINE INCLUDING THE GOODS, THE WATER, AND ANY REPEATED SINUSOIDAL (ROTATING) FORCE GENERATED DURING ITS OPERATION. WRITE THE FACTORY FOR ADDITIONAL MACHINE DATA FOR USE BY A COMPETENT SOIL AND/OR STRUCTURAL ENGINEER.

72044SR2/SR3 DWG# BD7244SPBE 2017355D PELLERIN MILNOR CORPORATION
P.O. Box 400 Kenner, LA 70063, USA, Phone 504/467–9591,
FAX 504/469–1849, Email: milnorinfo@milnor.com