
Sure-Weld® ROOFING SYSTEM

CREASE MEMBRANE AT ANGLE CHANGE TO LIMIT BRIDGING TO 3/4" (19 mm) MAXIMUM



- 1. BONDING ADHESIVE IS NOT REQUIRED WHEN FLASHING HEIGHT IS 12" (300 mm) OR LESS AND MEMBRANE IS FASTENED "AS SHOWN" AT TOP OF CURB.
- 2. WHEN CARLISLE TERMINATION BAR IS USED BENEATH THE COUNTERFLASHING, BONDING ADHESIVE CAN BE ELIMINATED WHEN THE FLASHING HEIGHT IS 18" (500 mm) OR LESS.
- 3. FLASHING MEMBRANE FASTENED APPROXIMATELY 12" ON CENTER. IF FASTENER PENETRATES METAL COUNTERFLASHING, USE NEOPRENE WASHER OR APPLY WATER CUT-OFF MASTIC UNDER COUNTERFLASHING OR CAULK FASTENER HEAD.
- 4. APPROXIMATELY 1/8" (3 mm) BEAD OF CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF SURE-WELD REINFORCED MEMBRANE.
- 5. REFER TO SPECIFICATION FOR ACCEPTABLE CARLISLE FASTENERS AND PLATES.
- 6. FOR CORNER FLASHING, REFER TO APPLICABLE SW-15 DETAIL.

CURB FLASHING

SW-5A