

BLOCKING NOTE:

PLACE SOLID BLOCKING AT ENDS OF FLOOR SYSTEM, ADJACENT TO ALL OPENINGS, AND AT 10'-0"o.c. MAX.

STRAP NOTE:


TOP STRAP NOT REQ'D. IF CONTINUOUSLY ATTACHED RIGID SHEATHING IS USED. TEMPORARY BRACING OF TOP FLANGE DURING CONSTRUCTION MAY BE REQ'D.

MIN. 18 GA RUNNER TRACK
SOLID BLOCKING @ 10'-0"o.c.
MAX. MAKE RUNNER TRACK 8"
LONGER THAN JOIST INSIDE
SPACING. CLIP FLANGES OF
TRACK 4" FROM EACH END.
BEND TRACK AT CLIPPED FLANGES.

ATTACH BLOCKING TO
JOISTS w/(2)#10-16
SCREWS IN EACH FLANGE
AS SHOWN.

(1)#10-16
SCREW IN EACH
JOIST FLANGE

1-1/2" x 20 GA. STRAPPING
ON TOP & BOTTOM OF JOISTS.
(STRAPPING TO START, END,
& SPLICE AT SOLID BLOCKING)



BRIDGING RECOMMENDATIONS	
SPANS	ROWS REQUIRED
UP TO 14'	ONE ROW @ MID-SPAN
14' TO 20'	TWO ROWS @ THIRD POINTS
20' TO 26'	THREE ROWS @ QUARTER POINTS



ClarkWestern
Building Systems

Design Services

20 Mansell Court East, Ste 350B | 6510 General Drive | 383 U.S. Route One, Ste 2E
Roswell, GA 30076 | Riverside, Ca. 92509 | Scarborough, ME 04074
toll free 877.832.3206 fax 877.832.3208

JOIST BRIDGING

1-1/2" x 20GA. STRAP WITH
RUNNER TRACK BLOCKING