

RL MUST BE DOUBLED.

RIGHT HAND OPPOSITE

PROVISIONS BY OTHERS

*GENERAL

HOISTWAY- THE HOISTWAY MUST BE IN ACCORDANCE WITH

"SAFETY CODE FOR ELEVATINGS AND ESCALATORS" (ASME AL7.1) AND ALL STATE AND LOCAL CODES.

PLIMB HOLSTWAY— DUE TO CLOSE RUNNING CLEARANCES OWNER/AGENT HUST ENSURE THAT HOLSTWAY AND PIT (WHERE PROVIDED) ARE LEVEL, PLUMB AND SQUARE AND ARE IN ACCORDANCE WITH THE ODNERSIONS ON THESE BRAVINGS.

DDMENSIONS ON THESE IRRAVINGS.

MINIMUM DIVERMENT CLEARANCE— OWNER/AGENT MUST ENSURE MINIMUM DVERHEAD CLEARANCE IS IN COMPLIANCE WITH CODES.

CONSTRUCTION STIL— DWNER/AGENT TO PROVIDE ALL MASDNRY, CARPENTRY AND DRYWALL WORK AS REQUIRED AND SHALL PATCH AND MAKE GOOD CINCLUDING FINISH PAINTINGS ALL AREAS WHERE WALLS/FLODES MAY REQUIRE TO BE CUT, DELLLED OR ALTERED IN ANY WAY TO PERMIT THE PROPER INSTALLATION OF THE LIFT.

DINENSIONS.

CONTRACTOR/CUSTOMER TO VERIFY ALL DIMENSIONS AND REPORT ANY DISCREPANCIES TO CUR OFFICE DIMEDICATELY.

*STRUCTURAL

STRUCTURE TO ANCHOR A CRANK SHAFT AND SAFETY HARNESS, WHERE APPLICABLE/NEEDED, TO BE PROVICED BY CONTRACTOR. CONTRACTOR TO ASSURE THAT BUILDING AND SHAFT WILL SAFELY SUPPORT ALL LOADS IMPOSED BY THE LIFT EQUIPMENT. REFER TO THE TABLES ON THIS DRAWING FOR LOADS IMPOSED BY THE EQUIPMENT.

*MACHINE ROOM (WHERE REQUIRED)

LEVEL AUJACENT TO HOISTVAY, INLESS SHOWN OTHERWISE ON THE LAYOUT DRAWINGS. FIELD ADJUSTMENT BY INSTALLER MAY BE NECESSARY TO MEET JOB SITE CONDITIONS OR REGULATIONS. MACHINE ROOM DOOR IS TO BE LOCKABLE AND IS TO MEET TO REGULREMENTS OF THE AUTHORITY HAVING JURISDICTION. SLEEVES FOR ELECTRIC LINES—FROM MACHINE ROOM TO HOISTWAY AS REQUIRED. (POSITION PER INSTALLERS INSTRUCTIONS).

			DIISCOWNECT Size						PHASE	FLA	
Motor	8,	EQUIP.	30	AMPS	30	AMPS	208	volt	Three Phase	28.9	AMPS
Notor	ŀ,	EQUIP.	60	AMPS	40	AMPS	530	volt	Single Phase	35.0	ZAMPS
CAB	L[2THD	15	AMPS	15	AMPS	115	V	Single Phase		

POWER SUPPLY— (SEE SPECIFICATIONS) LOCKABLE FUSED DISCONNECT WITH AUXILIARY CONTACT TO BRAKE THE BATTERY FEED, OR CIRCUIT BREAKERS WITH A 3-FOLL SREAKER FOR BATTERY FEED REQUIRED, IN COMPLIANCE WITH ELECTRICAL CODE, AS FOLLOWS.

(LOCATED ON WALL ON LOCK JAND SIDE OF MACHINE ROOM DOOR) PERMANENT POWER- BEFORE INSTALLATION CAN BEGIN, PERMANENT POWER MUST BE SUPPLIED.

LIGHTING- THE ILLUMINATION SHALL BE NOT LESS THAN BOO LX (19 FC) AT THE FLOOR LEVEL IN ALL MACHINE ROOMS AND MACHINERY SPACES. ENSURE AT LEAST 100 LX (10 FC) AMBIENT LIGHTING DIVER LIFT AREA. PHONE - NEED A DEDICATED PHONE LAND LINE

*ENTRANCES

FASCIA PANEL BLOW UPPER LEVEL ENTRANCE— WHERE REDUIRED, FASCIA PANEL MUST BE FASTENED TO A SOLID WALL AND BE PERPENDICULAR TO THE FLOOR AND WALLS. HISTWAY FASCIA IS NOT SELF-SUPPORTING FOR LINK, CONTINUOUS RUNS VOICE OF ENTRANCES. ADEQUATE SUPPORT FOR THE FASCIA MUST BE PROVIDED .

NOTE LIFTING BEAM:
A 4000LB MIN SML BEAM MUST BE PROVIDED IN THE
OVERHEAD, BEAM TO BE POSITIONED AS SHOWN IN
ELEVATION & PLAN VIEWS. FOR OVERHEAD OF 108".
POSITION THE UNDERSIDE OF BEAM AT 104" & BEAM
MUST BE TEMPORARY.

NOTE C ALL INFORMATION IS SUBJECT TO CHANGE. PLEASE REFERENCE DUR DN-LINE DRAVINGS AT WWW.savaria.com FOR THE MOST RECENT UPDATES

RESIDENTIAL ELEVATOR ZENITH MODEL 40X48 TYPE 1R

CUSTOMER THE DIFTORNATION COOLINGS WEREIN IS THE EXCLUSIVE PROPERTY OF PROJECT NAME OF THE LOCATION Ale HIV HOT BE ESED IN OTHERS VIOLENT PEOR VIETTON BOX