


INSTALLATION STEPS:

1. AFFIX BOTTOM TRACK TO FLOOR USING APPROPRIATE QUANTITY OF ANCHORS OR SCREWS.
2. AFFIX T-KNEE WALL SUPPORT BRACKET ASSEMBLY TO TRACK AND FLOOR USING FOUR (4) ANCHORS, TWO (2), OR ONE (1) ANCHORS AS NEEDED FOR LOAD CONDITIONS. FOLLOW ANCHOR MANUFACTURER'S INSTALLATION INSTRUCTIONS.
3. AFFIX ONE STUD (SHORT) TO T-KNEE WALL SUPPORT BRACKET ASSEMBLY WITH AT LEAST THREE (3) ROWS OF TWO (2) SCREWS IN THE TOP, MIDDLE, & BOTTOM.
4. AFFIX TOP AND BOTTOM TRACKS TO STUDS USING TWO (2) SCREWS.



T-KNEE WALL SUPPORT BRACKET ASSEMBLY



Telling® Industries, LLC.

THE LEADER IN METAL
FRAMING INNOVATION

www.BuildStrong.com
866- FRAME-TI (372-6384)

This drawing serves as a reference only and should not substitute the expertise of a qualified architect or engineer. It is intended to aid in the development of cold-formed steel framing construction details. A thorough evaluation and approval by a qualified architect or engineer are required.