


2

1

INSTALLATION STEPS:

1. AFFIX TAT SLOTTED TRACK TO CEILING USING SCREWS
2. ALIGN STUDS LEAVING A GAP BETWEEN THE TOP OF EACH STUD AND THE WEB OF THE TAT SLOTTED TRACK
3. AFFIX A SCREW IN EACH STUD FLANGE THROUGH THE SLOTS PROVIDED IN THE TAT FLANGE



TAT SLOTTED TRACK



Telling® Industries, LLC.

THE LEADER IN METAL
FRAMING INNOVATION

www.BuildStrong.com
866- FRAME-TI (372-6384)

This drawing serves as a reference only and should not substitute the expertise of a qualified architect or engineer. It is intended to aid in the development of cold-formed steel framing construction details. A thorough evaluation and approval by a qualified architect or engineer are required.

2

1