




FASTEN MEMBRANE AND FLASH CURB OR WALL WITH CURED EPDM MEMBRANE FOLLOWING STANDARD PROCEDURES.



USE PRE-CUT T-JOINT COVERS OR CUT A 6"x6" (15X15cm) & 12"x12" (30X30cm) SECTION OF QUICK-APPLIED UNCURED EPDM FLASHING AND ROUND CORNERS



CLEAN EPDM SPLICE AREA WITH WEATHERED MEMBRANE CLEANER PRIOR TO APPLYING EPDM PRIMER




REMOVE & REPLACE POLY
BACKING ON FLASHING. FOLD
FLASHING IN HALF WITH
ROUNDED PORTION TURNED UP.
CENTER ON CORNER & FIRMLY
PRESS AGAINST VERTICAL
SURFACE





ROLL & CREASE FLASHING TIGHTLY INTO ANGLE CHANGE & FIRMLY ROLL FLASHING ONTO THE DECK MEMBRANE

USE HEAT GUN TO WARM THE FLASHING IN COLD WEATHER




ROLL WITH A TWO INCH WIDE STEEL HAND ROLLER. PAY PARTICULAR ATTENTION TO THE STEP OFFS AND ANGLE CHANGES





APPLY EPDM PRIMER TO SPLICE AREA. INSTALL THE 12"X12" (30cmX30cm) SECTION OF QUICK-APPLIED UNCURED EPDM FLASHING CENTERED OVER PREVIOUSLY APPLIED FLASHING.



MAXIMUM WARRANTY: 30 YEARS



OUTSIDE CORNER FLASHING FOR PROJECTS WITH 90-MIL MEMBRANE OR 25 / 30 YEAR WARRANTIES



→ APPROVED SUBSTRATE

O → SEE NOTE(S)

THERMOSET ROOFING SYSTEM

VGC-15.7A