


## CONTINUOUS WALL FLASHING



## SEPARATE WALL FLASHING



## CONTINUOUS WALL FLASHING




## NOTES:

- 1. APPLY LAP SEALANT ALONG THE LEADING EDGE OF THE MEMBRANE SPLICE (UNDER THE QUICK-APPLIED UNCURED EPDM FLASHING) COVERING THE EXPOSED SPLICE TAPE APPROXIMATELY 1/2" (1.5cm) BEYOND THE SPLICE EDGE.
- 2. QUICK-APPLIED T-JOINT COVER OR 6"
  (15cm) WIDE QUICK-APPLIED FLASHING, IN
  CONJUNCTION WITH EPDM PRIMER, MUST BE
  CENTERED OVER FIELD SPLICES AT THE
  ANGLE CHANGE.
- 3. PROJECTS WITH 25 AND 30-YEAR WARRANTIES OR WHEN USING 90-MIL MEMBRANE REQUIRE FIELD SPLICES TO BE OVERLAID WITH TWO LAYERS OF QUICK-APPLIED UNCURED EPDM FLASHING. THE BOTTOM LAYER SHALL BE 6" (15cm) WIDE COVERED WITH A 12" (30cm) WIDE TOP LAYER. BOTH LAYERS SHALL BE CENTERED.
- 4. SEAL EXPOSED LAYER WITH LAP SEALANT.

MAXIMUM WARRANTY: 30 YEARS



EPDM MEMBRANE SPLICES AT ANGLE CHANGE



THERMOSET ROOFING SYSTEM

VGC-2.3