


CONTINUOUS WALL FLASHING



SEPARATE WALL FLASHING



(CONTINUOUS WALL FLASHING)



NOTES:

- 1. APPLY LAP SEALANT ALONG THE LEADING EDGE OF THE MEMBRANE SPLICE (UNDER THE QUICK APPLIED UNCURED EPDM FLASHING) COVERING THE EXPOSED SPLICE TAPE APPROXIMATELY 2" (51mm) BEYOND THE SPLICE EDGE.
- 2. QUICK APPLIED T-JOINT COVER OR 6"
 (152mm) WIDE QUICK APPLIED FLASHING, IN
 CONJUNCTION WITH EPDM PRIMER, MUST BE
 CENTERED OVER FIELD SPLICES AT THE
 ANGLE CHANGE. PROJECTS WITH 25 AND
 30-YEAR WARRANTIES OR WHEN USING
 90-MIL MEMBRANE REQUIRE FIELD SPLICES
 TO BE OVERLAID WITH TWO LAYERS OF
 QUICK APPLIED UNCURED EPDM FLASHING.
 THE BOTTOM LAYER SHALL BE 6" (152mm)
 WIDE COVERED WITH A 12" WIDE TOP
 LAYER (305mm). BOTH LAYERS SHALL BE
 CENTERED AND SEALED WITH CONTINUOUS
 LAP SEALANT.



EPDM MEMBRANE SPLICES AT ANGLE CHANGE



THERMOSET ROOFING SYSTEM

VGC-2.3